


CobbleTac Maintenance Instructions

In order to ensure your CobbleTac porcelain Tactile installation continues to look great and more importantly retain compliance to the Australian Standards, it requires regular monitoring and maintenance, up to and including regular cleaning and attention to any damage.

CTA Australia recommends the following maintenance regime:

1. INITIAL COMMISSIONING

It is important that your initial installation is cleaned and in most cases where CTA has supplied and installed the product, it will be conducted by the installation team.



REMOVAL OF ANY EXCESS ADHESIVE

WASH & SCRUB

ALLOW TO DRY

INSPECT

2. ONGOING DAILY MAINTENANCE

Depending on the type of installation and aesthetic requirement, CobbleTac porcelain Tactile should be swept clean of any debris on a daily basis. Note this is also an important safety requirement.




SWEEP OR VACUUM

INSPECT

3. ONGOING MONTHLY & BIANNUAL MAINTENANCE

CobbleTac is manufactured from high tensile porcelain and has a solid fl at base which will spread and absorb heavy loads. When installed correctly CobbleTac is proven to last the test of time. However, it is important the installation is inspected on a regular basis for any damage or dislodgement caused by unforeseen circumstances, such as vandal damage. On a biannual basis CTA recommends that CobbleTac porcelain Tactile is washed using a PH neutral detergent, with warm water and a deck broom to remove any excess dirt and grime.



WASH

INSPECT

Carrying out the recommended maintenance instructions will ensure your CobbleTac porcelain Tactile installation will last the test of time, remain safe and guarantee you conform with the standards at all times.

Please consult your local CTA distributor of CobbleTac porcelain Tactile for further advice.

Note: As an additional service to our clients, CTA Australia can provide a fully integrated maintenance program, which includes regular scheduled maintenance and replacement of components, where necessary. Please ask your CTA distributor for your "CTA Complete Care" maintenance program.